## CatGenie Gives You 4 Ways to Customize Cat Activation

## 14-HOUR CAT ACTIVATION

**14 Hrs Awake / 10 Hrs sleep.** Sleeps day or night. You decide.

10-Min Delay before cleaning. Suitable for 1 cat or cats who will only use a clean box everytime.

#1

Press & Release AutoSet Button until #1 + CAT LEDs light #2

30-Min Delay before cleaning. Suitable for 2-3 cats who go together; don't mind a used box.

Press & Release AutoSet Button until #2 + CAT LEDs light 24-HOUR CAT ACTIVATION

**24 Hrs Awake / 0 Hrs sleep.** Always ready to clean after use.

#3

10-Min Delay before cleaning. Suitable for 1 cat or

cats who will only use a clean box everytime.

Press & Release

AutoSet Button until
#3 + CAT LEDs light

#4

30-Min Delay before cleaning. Suitable for 2-3 cats who go together; don't mind a used box.

Press & Release AutoSet Button until #4 + CAT LEDs light

Set a

Set at the time you want your CatGenie to wake up.
In 1 & 2, you MUST lock in your start-time.
Press & Hold AutoSet for 4 seconds.

Do at any time to begin the 24 hour setting.

Press & Hold AutoSet Button for 5 seconds then release.

Your CatGenie stays on the Cat Activation mode you selected until you change it.

To **CHANGE** or **DE-ACTIVATE** any Cat Activation Mode: Press & Release the Auto Set Button until the LEDs go out. Both 14 & 24 hour Cat Activation options double the number of SaniSolution Cartridge washes from 120 to 240. If another cat uses the CatGenie during a Delay, the unit adjusts to allow more wait-time before starting. **TIP:** Make sure your cats are using their CatGenie before setting Cat Activation.




## Your CatGenie needs only 10 seconds of maintenance every 3 months...

To keep running properly and efficiently, every appliance requires a little maintenance. The CatGenie has a Water Sensor Guide that needs cleaning every 3 months.



The Water Sensor Guide is a 4" double bar of clear plastic located under 1) the Processing Unit. Lift the Unit, 2) see the ends of the Guide, pull it out and 3) wipe its triangular tip with your fingers or a damp towel until shiny. See page 16 of the Owners Manual for full details.

**TIP:** Cleaning the Guide takes no time and saves trouble. A dirty Guide sends a false signal, which causes the CatGenie to go into a safety mode that won't allow it to fill with water. This means it won't clean until you clean the Water Sensor Guide.



## and if you don't take care of your CatGenie, it warns you until you do.

When you **HEAR** one beep going on & off for 30 seconds every hour **AND** you **SEE** the #1 LED plus the ERROR LED blink together on & off every 3 seconds, you know you better clean your Water Sensor Guide.